

maximo

USER'S MANUAL
SOLAR INVERTER

PV4048 HM &
PV5048 HM

Version 10 August 2018

Appliances



PC



TV



Air-conditioning



Fridge



Washing machine

Table of Contents

| | |
|---|----|
| ABOUT THIS MANUAL | 1 |
| Purpose | 1 |
| SAFETY INSTRUCTIONS | 1 |
| INTRODUCTION | 3 |
| Features | 3 |
| Basic System Architecture | 3 |
| Product Overview | 4 |
| INSTALLATION | 5 |
| Unpacking and Inspection | 5 |
| Preparation | 5 |
| Mounting the Unit | 5 |
| Battery Connection | 6 |
| AC Input/ Output Connection | 8 |
| PV Connection | 10 |
| Communication Connection | 11 |
| Dry Contact Signal | 11 |
| Connecting the CAN Cable | 11 |
| OPERATION | 12 |
| Power ON/OFF | 12 |
| Operation and Display Panel | 12 |
| LCD Display Icons | 13 |
| LCD Setting | 15 |
| Fault Reference Code | 20 |
| Warning Indicator | 22 |
| Operating Mode Description | 23 |
| Display Setting | 25 |
| SPECIFICATIONS | 26 |
| Table 1 Line Mode Specifications | 26 |
| Table 2 Inverter Mode Specifications | 27 |
| Table 3 Charge Mode Specifications | 28 |
| Table 4 General Specifications | 29 |
| TROUBLE SHOOTING | 29 |
| Appendix: Approximate Back-up Time Table | 30 |

ABOUT THIS MANUAL

Purpose

This manual describes the assembly, installation, operation and troubleshooting of this unit. Please read this manual carefully before installations and operations. Keep this manual for future reference.

Scope

This manual provides safety and installation guidelines as well as information on tools and wiring.

SAFETY INSTRUCTIONS



WARNING: This chapter contains important safety and operating instructions. Read and keep this manual for future reference.

1. Before installing the inverter, read all instructions and cautionary markings on the inverter, the batteries and all appropriate sections of this manual.
2. **CAUTION** – Only use rechargeable deep-cycle lead acid type flooded, AGM or GEL batteries. or Lithium batteries. Other types of batteries may burst, causing injury and damage.
3. Do not disassemble the inverter. Take it to a qualified service center when service or repair is required. Incorrect re-assembly may result in a risk of electric shock or fire.
4. To reduce risk of electric shock, disconnect all wirings before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
5. **CAUTION** --Only qualified personnel should install this inverter and connect batteries.
6. **NEVER** charge a frozen battery.
7. For optimum operation of this inverter/charger, please follow required spec to select appropriate cable size. It's very important to correctly operate this inverter.
8. Be very cautious when working with metal tools on or around batteries. A potential risk exists to drop a tool to spark or short circuit batteries or other electrical parts and could cause an explosion.
9. Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to INSTALLATION section of this manual for the details.
10. A Battery Isolator of appropriate size needs to be installed as over-current protection between the inverter and the battery.
11. **GROUNDING INSTRUCTIONS**- This inverter should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
12. **NEVER** cause AC output and DC input short circuited. Do NOT connect to the mains when DC input short circuits.
13. **Warning!!** Only qualified service persons should service this inverter. If errors persist after following the troubleshooting table, please send this inverter back to local dealer or service center for maintenance.

INTRODUCTION

This is a multi-function inverter/charger, combining the functions of inverter, MPPT solar charger and battery charger to offer uninterruptible power supply. Its comprehensive LCD display offers user-configurable and easy-accessible button operation such as battery charging current, AC/solar charger priority, and acceptable input voltage based on different applications.

Features

- Pure sine wave inverter, with built-in MPPT solar charge controller
- Built-in automatic generator start function, 2-wire start
- Configurable input voltage range for home appliances and personal computers via LCD setting
- Configurable battery charging current based on applications via LCD setting
- Configurable AC/Solar Charger priority via LCD setting
- Compatible to mains voltage or generator power
- Auto restart while AC is recovering
- Overload/ Over temperature/ short circuit protection
- Smart battery charger design for optimized battery performance
- Cold start function

Basic System Architecture

The following illustration shows a basic application for this inverter/charger. It also includes following devices to have a complete running system:

- Generator
- PV modules

Consult with your system integrator for other possible system architectures depending on your requirements.

This inverter can power all kinds of appliances in home or office environment, including motor-type appliances such as tube light, fan, refrigerator and air conditioner.







Figure 1 Hybrid Power System

Product Overview



4KVA-5KVA parallel model



4KVA-5KVA single model

NOTE: For parallel model installation and operation, please check separate parallel installation guide for the details.

1. LCD display
2. Status indicator
3. Charging indicator
4. Fault indicator
5. Function buttons
6. Power on/off switch
7. AC input
8. AC output
9. PV input
10. Battery input
11. Circuit breaker
12. RS485 communication port
13. Parallel communication port (only for parallel model)
14. Parallel switch
15. Dry contact
16. USB

INSTALLATION


Unpacking and Inspection

Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. You should have received the following items inside of package:

- The unit x 1
- User manual x 1
- Communication cable x 1
- USB cable x 1
- Software CD x 1

Preparation


To be able to connect all wiring, take off bottom cover by removing four screws as shown below.



Mounting the Unit


Consider the following points before selecting where to install:

- Do not mount the inverter on flammable construction materials.
- Indoor use only, IP 20 rated, avoid direct sunlight
- Mount on a solid surface.
- Install this inverter at eye level in order to allow the LCD display to be read at all times.
- For proper air circulation to dissipate heat, allow a clearance of approx. 20 cm to the side and approx. 30 cm above and below the unit.
- The ambient temperature should be between 0°C and 55°C to ensure optimal operation.
- The recommended installation position is vertically to the wall.
- Be sure to keep other objects away as shown in the diagram to guarantee sufficient heat dissipation and to have space for removing wires



⚠ SUITABLE FOR MOUNTING ON NON-COMBUSTIBLE SURFACE ONLY.

Install the unit by screwing three screws




Battery Connection

CAUTION: For safe operation and regulation compliance, it's required to install a separate DC over-current protector or isolator between battery and inverter. It may not be required to have a battery isolator in some applications, however, it's still required to have an over-current protection installed. Please refer to table below for typical amperage to determine required fuse or breaker and cable size.

WARNING! All wiring must be performed by a qualified person.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for battery connection. In a parallel system (two or three units) make the battery cables the same length.

Ring terminal:




| Model | Typical Amperage | Battery Capacity | Wire Size | Ring Terminal | | | Torque Value |
|-------|------------------|------------------|-----------|-----------------------|------------|-------|--------------|
| | | | | Cable mm ² | Dimensions | | |
| | | | | | D(mm) | L(mm) | |
| 4048 | 66A | 200AH | 1*4AWG | 22 | 6.4 | 33.2 | 2~3Nm |
| | | | 2*8 AWG | 14 | 6.4 | 29.2 | |
| 5048 | 87A | 200AH | 1*4AWG | 22 | 6.4 | 33.2 | 2~3Nm |
| | | | 2*8 AWG | 14 | 6.4 | 29.2 | |

Please follow below steps to implement battery connection:

1. Fit recommended cable lugs to battery cables.
2. Connect batteries to make a 48V battery bank. Suggested battery capacity is at least 200Ah for the 4KVA/5KVA inverter model.

NOTE: Only use Deep Cycle Flooded/GEL/AGM lead acid battery or approved Lithium batteries.



3. Insert the cable lugs of battery cable flatly into the M6 battery connector of the inverter and make sure the nuts are tightened with a torque of 2-3 Nm. Making sure polarity at both the battery/battery isolator and the inverter is correctly connected.



WARNING: Shock Hazard

Installation must be performed with care due to high battery voltage in series.



CAUTION!! Do not place anything between the flat part of the inverter terminal and the ring terminal. Otherwise, overheating may occur.

CAUTION!! Do not apply anti-oxidant substance on the terminals before terminals are connected tightly.

CAUTION!! Before making the final DC connection or closing DC breaker/isolator, be sure positive (+) must be connected to positive (+) and negative (-) must be connected to negative (-).

AC Input / Output Connection

CAUTION!! Before connecting to AC input power source, please install a separate AC breaker between inverter and AC input power source. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current of AC input. The recommended spec of AC breaker is 40A for 4KVA and 50A for 5KVA.

CAUTION!! There are two terminal blocks with "IN" and "OUT" markings. Please do NOT-misconnect input and output connectors.

WARNING! All wiring must be performed by a qualified person.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable size as below.


Suggested cable requirement for AC wires

| Model | Gauge | Torque Value |
|-------|-------|--------------|
| 4KVA | 10AWG | 1.4~1.6Nm |
| 5KVA | 8AWG | 1.4~1.6Nm |

Please follow below steps to implement AC input/output connection:

1. Before making AC input/output connection, be sure to open DC protector or disconnect first.
2. Remove insulation sleeve 10mm for six conductors. And shorten phase L and neutral conductor N 3mm.
3. Insert AC input wires according to polarities indicated on terminal block and tighten the terminal screws. Be sure to connect PE protective conductor (⚡) first.

⚡ → **Ground (yellow-green)**
L → **LINE (brown or black)**
N → **Neutral (blue)**




| | |
|---|--|
| ⚠ | WARNING: Be sure to that AC power source is disconnected before attempting to hardwire it to the unit. |
|---|--|

4. Then, insert AC output wires according to polarities indicated on terminal block and tighten terminal screws.

Be sure to connect PE protective conductor (⚡)first.

⚡ → **Ground (yellow-green)**
L → **LINE (brown or black)**
N → **Neutral (blue)**



5. Make sure the wires are securely connected.

CAUTION: Important

Be sure to connect AC wires with correct polarity. If L and N wires are connected reversely, it may cause AC short-circuited when these inverters are worked in parallel operation.

CAUTION: Appliances such as air conditioner are required at least 2~3 minutes to restart because it's required to have enough time to balance refrigerant gas inside of circuits. If a power shortage occurs and recovers in a short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check manufacturer of air conditioner if it's equipped with time-delay function before installation. Otherwise, this inverter/charger will trig overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner.

PV Connection

CAUTION: Before connecting to PV modules, please install a DC circuit breaker or DC isolator of appropriate size between inverter and PV modules.

WARNING! All wiring must be performed by a qualified person.

WARNING! It's very important for system safety and efficient operation to use appropriate cable size for PV module connection.

| Model | Typical Amperage | Cable Size | Torque |
|----------------------|------------------|------------|-----------|
| 4048/60A 5048/60A | 60A | 8 AWG | 1.4~1.6Nm |
| 4048/80A 5048/80A | 80A | 6 AWG | 2.0~2.4Nm |

PV Module Selection:


When selecting PV modules, please be sure to consider below parameters:


1. Open circuit Voltage (Voc) of PV array can not exceed 145Vdc in the coldest condition.
2. Open circuit Voltage (Voc) of PV array needs to be higher than minimum battery voltage

| Solar Charging Mode | | |
|------------------------------------|-----------|----------|
| INVERTER MODEL | 4048/60A | 5048/60A |
| | 4048/80A | 5048/80A |
| Max. PV Array Open Circuit Voltage | 145Vdc | |
| PV Array MPPT Voltage Range | 64~130Vdc | |
| Min. battery voltage for PV charge | 34Vdc | |

Please follow below steps to implement PV module connection:

1. Remove insulation sleeve 10 mm for positive and negative conductors
2. Check correct polarity of connection from PV array to PV input





3. Make sure the wires are securely connected

Recommended PV module configuration

| PV Module Spec. (reference) | Inverter Model | Q'ty of modules | Array output |
|--|-----------------|------------------------|--------------|
| Risen Energy RSM60-6-270P -270W -Vmp:30.67Vdc -Imp:8.79A -Voc:37.88Vdc -Isc:9.31A | 4048/60A | 3S 5P | Voc 113.64 V |
| | 5048/60A | 15 Panels 4050 Watt | Isc 46.55 A |
| | 4048/80A | 3S 6P | Voc 113.64 V |
| | 5048/80A | 18 Panels 4860 Watt | Isc 55.86 A |

Example: Array Voc 113.64V, coldest temperature -10°, Correction Factor 1.14,
effective Voc_max 129.5V. Use table below to find the appropriate Correction Factor

Voltage Correction Factors for Crystalline and Multi-Crystalline Silicon PV Modules

| Lowest expected operating temperature (°C) | Correction Factor |
|--|-------------------|
| 24 to 20 | 1.02 |
| 19 to 15 | 1.04 |
| 14 to 10 | 1.06 |
| 9 to 5 | 1.08 |
| 4 to 0 | 1.10 |
| -1 to -5 | 1.12 |
| -6 to -10 | 1.14 |
| -11 to -15 | 1.16 |
| -16 to -20 | 1.18 |
| -21 to -25 | 1.20 |
| -26 to -30 | 1.21 |
| -31 to -35 | 1.23 |
| -36 to -40 | 1.25 |

(Source: AS/NZS 5033:2014 Table 4.1)


Communication Connection

Please use supplied communication cable to connect inverter to PC. Insert bundled CD into a computer and follow on-screen instruction to install the monitoring software. For the detailed software operation, please check user manual of software inside of CD.

Dry Contact Signal

There is one dry contact (3A/250VAC) available on the rear panel. It could be used to deliver a signal to an external device when the battery voltage reaches warning levels to start a generator.

| Unit status | Condition | | | Dry contact port: | |
|-------------|--|--|--|-------------------|-------|
| | | | | NC&C | NO&C |
| Power Off | Unit is off and no output is powered. | | | Close | Open |
| Power On | output is powered from “AC in” | | | Close | Open |
| | Output is powered from Battery or Solar. | Program 01 set as “AC in” | Battery voltage<Low DC warning voltage | Open | Close |
| | | | Battery voltage>Setting value in Program 21 or battery charging reaches floating stage | Close | Open |
| | | Program 01 is set as SBU, SUB, solar first | Battery voltage<Setting value in Program 20 | Open | Close |
| | | | Battery voltage>Setting value in Program 21 or battery charging reaches floating stage | Close | Open |




Connecting the CAN Cable

The CAN cable enables communication between the inverter and Li-ion batteries with a CAN ports. The RS485 port on the inverter is used to communicate with the battery. Below chart shows the pin configuration of the inverter.


Below chart is showed RJ45 Pins define

| Pin | Define |
|-----|----------|
| 1 | RS-485-B |
| 2 | RS-485-A |
| 3 | GND |
| 4 | |
| 5 | CANL |
| 6 | CANH |
| 7 | |
| 8 | |



OPERATION


Power ON/OFF



Once the unit has been properly installed and the batteries connected, flick the On/Off switch (located on the right hand bottom corner of the case) to the ON position to turn the inverter on.



Operation and Display Panel

The operation and display panel, shown in below chart, is on the front panel of the inverter. It includes three indicators, four function keys and a LCD display, indicating the operating status and input/output power information.



LED Indicator


| LED Indicator | | | Messages |
|---------------|-------|----------|---------------------------------------|
| AC/INV | Green | Solid On | Output is powered by AC in Line mode. |









| | | | |
|--|--------|----------|---|
| | | Flashing | Output is powered by battery or PV in battery mode. |
|  CHG | Yellow | Flashing | Battery is charging or discharging. |
|  FAULT | Red | Solid On | Fault occurs in the inverter. |
| | | Flashing | Warning condition occurs in the inverter. |

Function Keys

| Function Keys | Description. |
|---------------|---|
| MENU | Enter or exit setting mode go to previous selection. |
| UP | Increase the setting data. |
| DOWN | Decrease the setting data. |
| ENTER | Hold 2s to enter setting mode. Press to confirm the selection and move to next selection. |

LCD Display Icons















| Icon | Function description |
|---|--|
| Input Source Information and Output Information | |
|  | Indicates the AC information |
|  | Indicates the DC information |
|  | Indicate input voltage, input frequency, PV voltage, battery voltage and charger current. Indicate output voltage, output frequency, load in VA, load in Watt and discharging current. |
| Configuration Program and Fault Information | |
|  | Indicates the setting programs |
|  | Indicates the warning and fault codes. Warning: 88  flashing with warning code. Fault: 88  lighting with fault code. |
| Battery Information | |
|  | Indicates battery level by 0-24%, 25-49%, 50-74% and 75-100% in battery mode and charging status in line mode. |







In AC mode, it will present battery charging status.

| Status | Battery voltage | LCD Display |
|---|-------------------|--|
| Constant Current mode/Constant Voltage mode | <2V/cell | 4 bars will flash in turns |
| | 2~2.083v/cell | Bottom bar solid, three top bars flashing. |
| | 2.083~2.167V/cell | Bottom two bars solid, two top bars will flash in turns. |
| | >2.167V/cell | Bottom three bars solid, top bar will flash. |
| Batteries are fully charged. | | 4 bars solid. |






In battery mode, it will present battery capacity.

| Load Percentage | Battery Voltage | LCD Display |
|------------------|-------------------------|---|
| Load >50% | <1.717V/cell |  |
| | 1.717V/cell~1.8V/cell |  |
| | 1.8~1.883V/cell |  |
| | >1.883 V/cell |  |
| 50% > Load > 20% | <1.817V/cell |  |
| | 1.817V/cell~1.9V/cell |  |
| | 1.9 V/cell ~1.983V/cell |  |
| | >1.983 V/cell |  |
| Load <20% | <1.867V/cell |  |
| | 1.867V/cell~1.95V/cell |  |
| | 1.95V/cell~2.033V/cell |  |
| | >2.033 V/cell |  |

Load Information

| | | | | |
|---|---|---|---|---|
| OVER LOAD | Indicates overload. | | | |
|   100% 25% | Indicates the load level by 0-24%, 25-50%, 50-74% and 75-100%. | | | |
| | 0%~25% | 25%~50% | 50%~75% | 75%~100% |
| |  |  |  |  |




Mode Operation Information

| | |
|---|--|
|  | Indicates unit connects to the mains. |
|  | Indicates unit connects to the PV panel. |
| BYPASS | Indicates load is supplied by "AC in" power. |
|  | Indicates the solar charger circuit is working. |
|  | Indicates the DC/AC inverter circuit is working. |
| Mute Operation | |
|  | Indicates unit alarm is disabled. |

LCD Setting

After holding the "ENTER" button for 2 seconds, the unit will enter setting mode. Press "UP" or "DOWN" to select the correct setting. Press "ENTER" to confirm the selection and move to the next step.

Setting Programs:

| Pro gra m | Description | Selectable option | |
|-----------------|-------------------------------------|--|--|
| 00 | Exit setting mode | Escape  | |
| 01 | Output source priority selection | (default)  | Solar provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, AC energy will supply power to the loads at the same time. The battery energy will supply power to the load only if AC power is unavailable. If solar power is unavailable, AC will charge the battery until the battery voltage reaches setting in point 21. If solar power is available, but the battery voltage is lower than the setting in point 20, AC will charge the battery until the battery voltage reaches the setting in point 20. |
| | |  | Solar energy provides power to the loads as first priority. If solar energy is not sufficient to power all connected loads, the battery will supply power to the loads at the same time. AC provides power to the loads only when battery voltage drops to either low-level warning voltage or the setting in point 20 or solar and battery is not sufficient. The battery energy will supply power to the load in the condition of the AC is unavailable or the battery voltage is higher than the setting in point 21 |

| | | | |
|----|------------------------|----------------------------------|--|
| | | | (when BLU is selected in point 5) or program 20(when LBU is selected in point 5). If solar power is available, but the battery voltage is lower than the setting in point 20, the AC will charge the battery until the battery voltage reaches the setting point in program 20. |
| | | [0] SOL | Solar energy provides power to the loads as first priority. If battery voltage has been higher than the setting point in program 21 for 5 minutes, and the solar energy has been available for 5 minutes too, the inverter will turn to battery mode, solar and battery will provide power to the loads at the same time. When the battery voltage drops to the setting in point 20, the inverter will turn to bypass mode, AC will provides power to the load only, and solar power will charge only the battery. |
| | | [0] Ut. | AC will provide power to the loads as first priority. Solar and battery energy will provide power to the loads only when AC power is not available. |
| 02 | AC input voltage range | Appliances (default) [02] APL | If selected, acceptable AC input voltage range will be within 90-280VAC. |
| | | UPS [02] UPS | If selected, acceptable AC input voltage range will be within 170-280VAC. |
| | | GEN [02] GEN | When the user uses the device to connect the generator, select the generator mode. |
| | | VDE [02] vde | If selected, acceptable AC input voltage range will conform to VDE4105 (184VAC-253VAC) |
| 03 | Output voltage | [03] 230 _v | Set the output voltage, (220VAC-240VAC) |
| 04 | Output frequency | 50HZ (default) [04] 500 | 60HZ [04] 600 |
| 05 | Solar supply priority | (default) [05] BLU | Solar energy provides power to charge battery as first priority. When AC is available, if the battery voltage is lower than the setting in point 21, solar energy will not supply to the load it will only charge the |

| | | | |
|----|---|--|--|
| | | | battery. If the battery voltage is higher than the setting point in program 21, the solar energy will supply to the load and recharge the battery. |
| | | [05] LbU | Solar energy provides power to the loads as first priority If the battery voltage is lower than the setting in point 20, solar energy will not supply power to the load, it will only charge the battery. If the battery voltage is higher than the setting in point 20, solar energy will supply to the load and recharge the battery. |
| 06 | Overload bypass: The unit will transfer to line mode if overload occurs in battery mode. | Bypass disabled [06] bYd | Bypass enabled (default) [06] bYE |
| 07 | Auto restart when overload occurs | Restart disabled [07] Lt d | Restart enabled [07] Lt E |
| 08 | Auto restart when over temperature occurs | Restart disabled [08] t t d | Restart enabled [08] t t E |
| 10 | Charger source priority: To configure charger source priority | If this inverter/charger is working in Line, Standby or Fault mode, charger source can be programmed as below: | |
| | | Solar first [10] cS0 | Solar energy will charge battery as first priority. AC will charge the battery only when solar energy is not available. |
| | | Solar and “AC in” [10] sNu | Solar energy and AC will charge battery at the same time. |
| | | Only Solar [10] oS0 | Solar energy will be the only source to charge the battery |
| | | If this inverter/charger is working in Battery mode or Power saving mode, only solar energy can charge the battery. Solar energy will charge battery if it's available and sufficient. | |
| 11 | Maximum total charging current: Solar and AC input | 60A model (default) [1] 60 A | Setting range is from 1 A to 120A. Increment of each click is 1A. |

| | | | |
|----|-----------------------------|---|--|
| | | 80A model (default) [1] 80 ^A | Setting range is from 1 A to 140A. Increment of each click is 1A. |
| 13 | Maximum AC charging current | 30A model (default) [13] 30 ^A | Setting range is from 1A to 60A. Increment of each click is 1A. |

| | | | |
|----|---|---|---|
| 14 | Battery type | AGM (default) Flooded [14]AGM [14]FLD | |
| | | GEL LEAD [14]GEL [14]LEA | |
| | | Lithium Ion User-Defined [14]LI [14]USE | |
| | | If "User-Defined" or “LI” is selected, battery charge voltage and low DC cut-off voltage can be set up in program 17, 18 and 19. | |
| 17 | Bulk charging voltage (C.V voltage) | 48V model default setting: 56.4V [17]CV 56.4 ^v | |
| | | If self-defined is selected in program 14, this program can be set up. Setting range is from 48.0V to 58.4V for 48Vdc model. Increment of each click is 0.1V | |
| 18 | Floating charging voltage | 48V model default setting: 54.0V [18]FLV 54.0 ^v | |
| | | If self-defined is selected in program 14, this program can be set up. Setting range is from 48.0V to 58.4V for 48Vdc model. Increment of each click is 0.1V | |
| 19 | Low DC cut off battery voltage setting | 48V model default setting: 40.8V [19]COV 40.8 ^v | |
| | | If self-defined is selected in program 14, this program can be set up. Setting range is from 40.0V to 48.0V for 48Vdc model. Increment of each click is 0.1V. Low DC cut-off voltage will be fixed to setting value no matter what percentage of load is connected. | |
| 20 | Battery stop discharging voltage when AC is available | Available options for 48V models: | |
| | | 46.0V (default) | Setting range is from 44.0V to 58.0V. Increment of each click is |

| | | | |
|----|--|--|--|
| | | [20] 46.0 _v | 0.1V |
| 21 | Battery stop charging voltage when AC is available | Available options for 48V models: 54.0V (default) [21] 54.0 _v | Setting range is from 44.0V to 58.0V. Increment of each click is 0.1V |
















| | | | |
|----|---|--------------------------------------|---|
| 22 | Auto turn page | (default) [22] P t E | If selected, the display screen will auto turn the display page. |
| | | [22] P t d | If selected, the display screen will stay at latest screen user finally switches. |
| 23 | Backlight control | Backlight on [23] L o n | Backlight off (default) [23] L o f |
| 24 | Alarm control | Alarm on (default) [24] b o n | Alarm off [24] b o f |
| 25 | Beeps while primary source is interrupted | Alarm on [25] A o n | Alarm off (default) [25] A o f |
| 27 | Record Fault code | Record enable(default) [27] F o n | Record disable [27] F o f |



After pressing and holding “MENU” button for 6 seconds, the unit will enter reset model. Press “UP” and “DOWN” button to select programs. And then, press “ENTER” button to exit.















| | | |
|--|-------------------------|-----------------------|
| | (default) [dt] n t t | Reset setting disable |
|--|-------------------------|-----------------------|

| | | |
|-----|----------|----------------------|
| SEt | [dt] 15t | Reset setting enable |
|-----|----------|----------------------|


Fault Reference Code













| Fault Code | Fault Cause | LCD Indication |
|------------|---------------------------------------|--|
| 01 | Fan is locked when inverter is off | [01]  ERROR |
| 02 | Inverter transformer over temperature | [02]  ERROR |
| 03 | battery voltage is too high | [03]  ERROR |
| 04 | battery voltage is too low | [04]  ERROR |
| 05 | Output short circuited | [05]  ERROR |
| 06 | Inverter output voltage is high | [06]  ERROR |
| 07 | Overload time out | [07]  ERROR |
| 08 | Inverter bus voltage is too high | [08]  ERROR |
| 09 | Bus soft start failed | [09]  ERROR |
| 11 | Main relay failed | [11]  ERROR |
| 21 | Inverter output voltage sensor error | [21]  ERROR |
| 22 | Inverter “AC in” voltage sensor error | [22]  ERROR |
| 23 | Inverter output current sensor error | [23]  ERROR |
| 24 | Inverter “AC in” current sensor error | [24]  ERROR |
| 25 | Inverter load current sensor error | [25]  ERROR |

| | | |
|----|------------------------------------|--|
| 26 | Inverter AC over current error | [26]  |
| 27 | Inverter radiator over temperature | [27]  |









| | | |
|----|---|--|
| 31 | Solar charger battery voltage class error | [31]  |
| 32 | Solar charger current sensor error | [32]  |
| 33 | Solar charger current is uncontrollable | [33]  |
| 41 | Inverter “AC in” voltage is low | [41]  |
| 42 | Inverter “AC in” voltage is high | [42]  |
| 43 | Inverter “AC in” under frequency | [43]  |
| 44 | Inverter “AC in” over frequency | [44]  |
| 51 | Inverter over current protection error | [51]  |
| 52 | Inverter bus voltage is too low | [52]  |
| 53 | Inverter soft start failed | [53]  |
| 55 | Over DC voltage in AC output | [55]  |
| 56 | Battery connection is open | [56]  |
| 57 | Inverter control current sensor error | [57]  |
| 58 | Inverter output voltage is too low | [58]  |


Warning Indicator

| Warning Code | Warning Event | Icon flashing |
|--------------|------------------------------------|--|
| 61 | Fan is locked when inverter is on. | [61]  |

| | | |
|----|--|--|
| 62 | Fan 2 is locked when inverter is on. | [62]  |
| 63 | Battery is over-charged. | [63]  |
| 64 | Low battery | [64]  |
| 67 | Overload | [67]   100% 25% |
| 70 | Output power derating | [70]  |
| 72 | Solar charger stops due to low battery | [72]  |
| 73 | Solar charger stops due to high PV voltage | [73]  |
| 74 | Solar charger stops due to over load | [74]  |
| 75 | Solar charger over temperature | [75]  |
| 76 | PV charger communication error | [76]  |
| 77 | Parameter error | [77]  |






Operating State Description

| Operation state | Description | LCD display |
|--|--|--|
| Match load state Note: DC power produced from your solar array is converted by the inverter into AC power, which is then sent to your main electrical panel to be used by your household appliances. Any excess power generated stored in the battery. | PV energy is charging the battery and providing AC power to the load | PV energy power is larger than inverter power  |
| | | PV energy power is smaller than inverter power  |
| | | PV is off  |
| Charge state | PV energy and generator are charging the batteries. |  |
| Bypass state | Error are caused by inside circuit error or external reasons such as over temperature, |  |
| Off-Grid state | The inverter will provide output power from battery and PV power. | Inverter power loads from PV energy.  |
| | | Inverter power loads from battery and PV energy.  |
| | | Inverter power loads from battery only.  |

| | | |
|-----------|--|--|
| Stop mode | The inverter stopped working. Turn off the inverter by the soft key and turn it back on. |  |
|-----------|--|--|

Display Setting

The LCD display information will be switched in turns by pressing "UP" or "DOWN" key. The selectable information is switched as below order: battery voltage, battery current, inverter voltage, inverter current, "AC in" voltage, "AC in" current, load in Watt, load in VA, "AC in" frequency, inverter frequency, PV voltage, MPPT charging power, MPPT charging output voltage, MPPT charging current.

| Selectable information | LCD display |
|---|--|
| Battery voltage/DC discharging current |  |
| Inverter output voltage/Inverter output current |  |
| "AC in" voltage / "AC in" current |  |
| Load in Watt/VA |  |
| AC frequency/Inverter frequency |  |

| | |
|---|--|
| PV voltage and power | |
| PV charger output voltage and MPPT charging current | |

SPECIFICATIONS

Table 1 Line Mode Specifications

| | |
|--|--|
| INVERTER MODEL | 4048/60A 4048/80A 5048/60A 5048/80A |
| Input Voltage Waveform | Sinusoidal |
| Nominal Input Voltage | 230Vac |
| Low Loss Voltage | 90Vac \pm 7V(APL、GEN);170Vac \pm 7V(UPS) 186Vac \pm 7V(VDE) |
| Low Loss Return Voltage | 100Vac \pm 7V(APL、GEN);180Vac \pm 7V(UPS) 196Vac \pm 7V(VDE) |
| High Loss Voltage | 280Vac \pm 7V(UPS、APL、GEN)253Vac \pm 7V(VDE) |
| High Loss Return Voltage | 270Vac \pm 7V(UPS、APL、GEN)250Vac \pm 7V(VDE) |
| Max AC Input Voltage | 300Vac |
| Nominal Input Frequency | 50HZ/60HZ (Auto detection) |
| Low Loss Frequency | 40HZ \pm 1HZ(UPS、APL、GEN) 47.5HZ \pm 0.05HZ(VDE) |
| Low Loss Return Frequency | 42HZ \pm 1HZ(UPS、APL、GEN) 47.5HZ \pm 0.05HZ(VDE) |
| High Loss Frequency | 65HZ \pm 1HZ(UPS、APL、GEN) 51.5HZ \pm 0.05HZ(VDE) |
| High Loss Return Frequency | 63HZ \pm 1HZ(APL、GEN、UPS) 50.05HZ \pm 0.05HZ(VDE) |
| Output Short Circuit Protection | Line mode: Circuit Breaker Battery mode: Electronic Circuits |
| Efficiency (Line Mode) | >95%(Rated R load, battery full charged) |
| Transfer Time | 10ms typical (UPS、VDE) 20ms typical (APL) |
| Output power derating: When AC input voltage drops | 230Vac model: |

to 95V or 170V depending on models, the output power will be de-rated.




Table 2 Inverter Mode Specifications

| | |
|--|--|
| INVERTER MODEL | 4048/60A 4048/80A 5048/60A 5048/80A |
| Rated Output Power | 4KVA/3.2KW 5KVA/4KW |
| Output Voltage Waveform | Pure Sine Wave |
| Output Voltage Regulation | 230Vac \pm 5% |
| Output Frequency | 60Hz or 50Hz |
| Peak Efficiency | 90% |
| Overload Protection | 5s@>150% load;10s@ 110%~150% load |
| Surge Capacity | 2* rated power for 5 seconds |
| Nominal DC Input Voltage | 48Vdc |
| Cold Start Voltage | 46.0Vdc |
| Low DC Warning Voltage @ load<20% @ 20% \leq load<50% @ load \geq 50% | 44.0Vdc 42.8Vdc 40.4Vdc |
| Low DC Warning Return Voltage @ load<20% @ 20% \leq load<50% @ load \geq 50% | 46.0Vdc 44.8Vdc 42.4Vdc |
| Low DC Cut-off Voltage @ load<20% @ 20% \leq load<50% @ load \geq 50% | 42.0Vdc 40.8Vdc 38.4Vdc |
| High DC Recovery Voltage | 58Vdc |
| High DC Cut-off Voltage | 60Vdc |
| No Load Power Consumption | <50W |

*4KVA/5KVA only supports 230VAC system.

Table 3 Charge Mode Specifications

| “AC in” Charging Mode | | |
|---|--|--|
| INVERTER MODEL | | 4048/60A 4048/80A 5048/60A 5048/80A |
| Charging Current @Nominal Input Voltage | | 1~60A |
| Absorption Voltage | SEALED-LEAD AGM/GEL Battery | 50 |
| | Flooded battery | 50 |
| Refloat Voltage | SEALED-LEAD AGM/GEL Battery | 54.8 |
| | Flooded battery | 54.8 |
| Float Voltage | SEALED-LEAD AGM/GEL Battery | 57.6 |
| | Flooded battery | 56.8 |
| Charging Algorithm | | 3-Step(Flooded Battery、Sealed-Lead、AGM/Gel Battery),4-Step(LI) |
| Solar Charging Mode | | |
| INVERTER MODEL | 4048/60A 5048/60A | 4048/80A 5048/80A |
| Rated Power | 3000W | 4000W |
| Solar Charging Current | 60A | 80A |
| Efficiency | 98.0% max. | |
| Max. PV Array Open Circuit Voltage | 145Vdc max | |
| PV Array MPPT Voltage Range | 64~130Vdc | |
| PV Array Isc | 60A | 80A |
| Min battery voltage for PV charge | 34Vdc | |
| Standby Power Consumption | 2W | |
| Battery Voltage Accuracy | +/-0.3% | |
| PV Voltage Accuracy | +/-2V | |
| Charging Algorithm | 3-Step(Flooded Battery、Sealed-Lead、AGM/Gel Battery),4-Step(LI) | |




Table 4 General Specifications

| INVERTER MODEL | 4048/60A 5048/60A | 4048/80A 5048/80A |
|-----------------------------------|---|----------------------|
| Certification | IEC62109-1, IEC62109-2, SAA180814, CE | |
| Operating Environment | IP20 Indoor use only, avoid direct sunlight | |
| Operating Temperature Range | 0°C to 55°C | |
| Storage temperature | -15°C to 60°C | |
| Back feed current to array | No back feed | |
| Inrush current | 40A | 40A |
| Max output fault current | 20.9A | 26A |
| Max output overcurrent protection | 15.3A | 19.1A |
| Dimension (D*W*H), mm | 354 x 272 x 128 | 528 x295 x141 |
| Net Weight, kg | 12.5 | 13.5 |

TROUBLE SHOOTING

| Problem | LCD/LED/Buzzer | Explanation/Possible cause | What to do |
|---|---|---|--|
| Unit shuts down automatically during startup process. | LCD/LEDs and buzzer will be active for 3 seconds and then complete off. | The battery voltage is too low (< 1.91V/Cell) | 1. Re-charge battery. 2. Replace battery. |
| No response after power on. | No indication. | 1. The battery voltage is far too low. (<1.4V/Cell) 2. Battery polarity is connected reversed. | 1. Check if batteries the wiring are connected and well. 2. Re-charge battery. 3. Replace battery. |
| Mains exist but the unit works in battery mode. | Input voltage is displayed as 0 on the LCD and green LED is flashing. | Input protector is tripped | Check if AC breaker is tripped and AC wiring is connected well. |
| | Green LED is flashing. | Insufficient quality of AC power | 1. Check if AC wires are too thin and/or too long. 2. Check if generator (if applied) is working well or if input voltage range setting is correct. (Appliance=>wide) |
| When the unit is turned on, internal relay is switched on and off repeatedly. | LCD display and LEDs are flashing | Battery is disconnected. | Check if battery wires are connected well. |
| Buzzer beeps continuously and red LED is on. | Fault code 07 | Overload error. The inverter is overload 110% and time is up. | Reduce the connected load by switching off some equipment. |
| | Fault code 05 | Output short circuited. | Check if wiring is connected well and remove abnormal load. |
| | | Internal temperature of inverter component is over 90°C. | |
| | Fault code 02 | | Check whether the air flow of the unit is blocked or whether the ambient temperature is too high. |
| | Fault code 03 | Battery is over-charged. | Return to repair center. |
| | | The battery voltage is too high. | Check if spec and quantity of batteries are meet requirements. |
| | Fault code 01 | Fan fault | Replace the fan. |
| | Fault code 06/58 | Output abnormal (Inverter voltage below than 202Vac or is higher than 253Vac) | 1. Reduce the connected load. 2. Return to repair center |
| | Fault code | Internal components filed. | Return to repair center |

| | | | |
|--|---------------|--|---|
| | 08/09/53/57 | | |
| | Fault code 51 | Over current or surge | Restart the unit, if the error happens again, please return to repair center. |
| | Fault code 52 | Bus voltage is too low | |
| | Fault code 55 | Output voltage is unbalanced | |
| | Fault code 56 | Battery is not connected, or fuse is faulty. | If the battery is connected correctly, please return the unit to the repair center. |

Appendix: Approximate Back-up Time Table

| Model | Load(VA) | Backup Time@48Vdc 100Ah(min) | Backup Time@48Vdc 200Ah(min) |
|-------|----------|------------------------------|------------------------------|
| 4KVA | 400 | 766 | 1610 |
| | 800 | 335 | 766 |
| | 1200 | 198 | 503 |
| | 1600 | 139 | 339 |
| | 2000 | 112 | 269 |
| | 2400 | 95 | 227 |
| | 2800 | 81 | 176 |
| | 3200 | 62 | 140 |
| | 3600 | 55 | 125 |
| | 4000 | 50 | 112 |
| 5KVA | 500 | 613 | 1288 |
| | 1000 | 268 | 613 |
| | 1500 | 158 | 402 |
| | 2000 | 111 | 271 |
| | 2500 | 90 | 215 |
| | 3000 | 76 | 182 |
| | 3500 | 65 | 141 |
| | 4000 | 50 | 112 |
| | 4500 | 44 | 100 |
| | 5000 | 40 | 90 |

Note: Backup time depends on the quality of the battery, age of battery and type of battery.
Specifications of batteries may vary depending on different manufacturers.